

APPLICATION INSTRUCTIONS FOR NEOPRENE SEAL

1. Apply ribbed neoprene seal to frame after finish paint is applied.
2. Apply to hinge jamb to make contact with hinge edge of door.
3. Top and strike edges of door are beveled. Use a business card and a short strip of neoprene to determine position where neoprene makes contact with door, but does not compress or drag. Then apply full length strip in this location.
4. On cam lift doors this will require seal at head section to taper in toward the magnetic seal starting 6" to 8" from the hinge edge, see detail below.

