

Removable Mullion at Acoustical Frames

- Removable Mullion (A) is factory installed with the Mullion Shoe (B) bolted to it.
- The Top Shoe[®] is factory-welded to the head of the frame.
- Carefully lay out the location of the Mullion Shoe (B) on the floor.
- The mullion MUST be plumb, square, and in plane with the frame.
- Use anchor bolts to fasten the bottom Mullion Shoe (B) to the floor.
- Be sure the oversized flanges on both (B) and (C) are located opposite the door side, as noted above.
- Reinstall Mullion (A) by sliding it into the opening from the “DOOR SIDE” of the frame, as noted above.
- Bolt the mullion to the top and bottom shoes.

