





Rev. 010524



Installation Instructions

STEP 1

• Install Krieger-supplied heavy duty lifting lugs into the tapped holes.

STEP 2

• After the door is hung securely in place, remove the lifting lugs and install the supplied set screw.

STEP 3

• Set the screws flush to the face of the door.

STEP 4

• Hide set screw holes by applying bondo. Let dry, then sand smooth and paint as desired.



