

MEETING STILE DETAILS FOR 3" THICK DOOR

INSTALLATION INSTRUCTIONS

- The neoprene seal on inactive door is integral and can be adjusted using the adjustment screw.
- The neoprene seal which runs the entire length of the door is cut long at the factory and must be trimmed accordingly. Cut an 1/8" passed the retainer on the top and contact the threshold on the bottom.
- The applied astragal mounts on the active door and runs the entire length of the door. The neoprene should extend each side by 1/8" to ensure a tight fit.
- To adjust the applied astragal inward you can shim behind the mounting screws as needed.

