

# FRAME INSTALLATION

The following recommendations and precautions are intended to ensure a quality installation of our products. *\*Please note that this is a general reference guide and each installation is unique. Please contact Krieger with any installation specific questions for assistance.*

Hollow metal doors and frames should be generally installed by qualified experienced journeyman carpenters. The spreader on the bottom of the frame is for transportation only. **Remove prior to frame installation.** Frames must be installed square (1), plumb (2), in plane (3) and not twisted (4) in order to achieve proper door alignment and seal contact. Check the diagonal dimensions and “cross string” the frame to insure that jambs are set correctly. Anchor the frame securely to the walls utilizing all the anchor points. Acoustical frames must be filled with sound deadening material to achieve the required acoustical rating. We further recommend that caulking be applied to the frame return at the wall interface to ensure a good, continuous seal.

**Under no circumstances should frames be installed on carpet, which will cause sound transmission and prevent the frame from performing as designed.**

