

Z BRACKET USE AND INSTALLATION

INSTALLATION INSTRUCTIONS

Krieger Z Brackets are used on our assemblies with an applied stop seal system. Any hardware that is mounted to the soffit of the frame will need a Z bracket. Ex. Closer arms, strikes etc. The Z Bracket mounts over the sound seal assembly (A) as shown below. This provides a rigid mounting surface for closers and other soffit mounted hardware.

Krieger provides a heavy gauge Z bracket (B), and 1/4-20" pan head machine screws (C). The frame also comes with a reinforcement plate for secure mounting of the brackets. The hardware installer is responsible for drilling and tapping to mount the bracket and hardware.

NOTE: NEVER MOUNT ANY HARDWARE ON THE SOUND SEAL COVERS!

