

PAINTING OF ACOUSTICAL DOORS

WARNING REGARDING PAINT AND VINYL SEALS

When painting Krieger acoustical doors it is important to let the paint fully cure to prevent any damage to the paint and also the sound seals. It is important that the paint fully cures with a hard smooth surface. Choosing the wrong paint or not letting paint fully cure can result in a condition known as plasticizer migration and occurs when solvents from uncured paint reacts with neoprene or vinyl gaskets. To avoid this condition make sure the paint is fully cured and no longer outgassing before adjusting the neoprene sound seals. Please be sure to use Low VOC solvent or water based paint to reduce paint outgassing from breaking down the gasket seal.

The flexible neoprene sound seals must never be painted under any circumstance as this will make the seal ineffective.

All paint/ primer applied at our factory must comply with California Air Resources standards.