

INSTRUCTIONS FOR REMOVABLE MULLIONS FOR RF & RF/STC FRAMES

NOTE: REMOVABLE MULLIONS MUST BE REMOVED PRIOR TO INSTALLATION.

INSTALLATION INSTRUCTIONS

Remove any installed seals from the frame, this is for shipping purposes only. Next, uninstall the mullion (A) from the upper and lower shoe (B and C) by removing the bolts on the front and back of each.

Install the frame according to our standards explained in IG# 300/300.1.

Select the appropriate floor anchor for your floor type. For a concrete floor we recommend a concrete stud anchor. Place the threshold into position and drill into the concrete floor with the appropriate size hole for your 3/8" anchor type. Install the two anchors and the threshold into position.

Note: The Krieger removable mullion height is designed to work with our stainless-steel threshold.

