




Rev. 010524



Materials Legend

- 1. Krieger electrosonic neoprene seal
- 2. Wall RF film (installed prior to frame)
- 3. Krieger removable trim
- 4. Stainless steel (SS) glass stops

- 5. ¹/₈" thick glazing tape
- 6. EMI glass
- 7. Laminate glass
- 8. 18-gauge perforated stop





Rev. 010524

Page 2 of 4



Installation Instructions

STEP 1

• Remove the four SS glass stops (4) from the frame.

STEP 2

• Apply the Krieger electrosonic neoprene seal (1) along the entire interior perimeter of the integral frame stop on the side of the opening containing the EMI glass (6).

STEP 3

• Install glazing tape (5) on the inside of the removable stops/vision lite frame as well as on perforated material (8). The tape should be applied to the entire perimeter of the glass in order to make continuous contact with the glazing on both sides.



If You Have Questions

Rev. 010524



STEP 4

- Thoroughly clean glass prior to installation. Follow manufacturer's instructions for cleaning polycarbonate and whitewater glass as certain cleaners may damage the glass.
- UL marking list must remain visible on the exterior side, if applicable.

STEP 5

- Line the perimeter of the of the frame where the edge glass will rest against it with two layers of ¹/₈" glazing tape (5) on the laminated glass side (7).
- Install the EMI glass (6) and reinstall the glass stops (4); repeat step for the laminate glass side.

End Instructions

